



Instructions for Attaching the *TIF-101RMK* (Rack Mount Kit) to the TIF-101 Phone Interface

Kit Includes:

- 1 Silkscreened, Punched, Rack Panel
- 2 Anodized Spacers
- 4 Pan Head Screws

A. **Front Plate replacement** –

- Remove four screws securing the front plate to the TIF-101
- Discard the four screws and the front plate
- Replace the rubber spacer with the included metal spacer
- Place the new Front Plate on the TIF-101. Align the LEDs and Switch to the appropriate holes
- Attach the Rack Panel with the included pan head screws

B. **Rear Spacer Replacement**

- Remove four screws securing the rear plate to the TIF-101
- Set aside the screws and the rear plate.
- Replace the rubber spacer with the included metal spacer
- Re-attach the rear plate with the original flat head screws.
- Remove the four rubber feet from the bottom of the TIF-101.
- Note: This Rear Spacer Replacement Procedure allows the TIF-101 to fit into a single unit space.